


*ASSEMBLY INSTRUCTION
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

203974
Mirror

REVISION 0 :07/18/2013
REVISION 1 :10/18/2016
REVISION 2 :01/07/2020

ITEM : 203974

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME


20 MINUTES

PARTS IDENTIFICATION

A MIRROR 1PC



B MIRROR SUPPORT (PACKED WITH DRESSER) 2PCS




C DRESSER *FROM BOX ITEM # 203973 1PC



HARDWARE IDENTIFICATION

1 FLAT HEAD SCREW (M4 x 32mm - RBW) 6PCS




NOTE :


Phillips head screw driver is required in the assembly process ; however, manufacturer does not provide this item.

ITEM : **203974**
ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2




STEP 3
COMPLETE



ITEM : 203974

COASTER
FINE FURNITURE



Note : Dimension tolerance $\pm 5\%$