

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

## 900082 ACCENT TABLE

REVISION 0:09/15/2017

PAGE 1 OF 5

COASTERFURNITURE.COM



COASTERFURNITURE.COM

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



#### PARTS IDENTIFICATION


А	TOP GLASS						1PC	
В	TOP FRAME						1PC	
С	LEFT FRAME						1PC	
D	RIGHT FRAME	≣					1PC	
E	CROSSBAR						1PC	
HARDWARE IDENTIFICATION								
1	BOLT (1/4" x 12mm SR)	0	8PCS	3	LEVELER (1/4" x 12mm)		4PCS	
2	SUCTION CUP (5mm)		4PCS	4	ALLEN WRENCH (4mm)		1PC	

PAGE 2 OF 5




STEP 1

Do not tighten until each step is completed or instructed.



## STEP 2




PAGE 3 OF 5


COASTERFURNITURE.COM



STEP 3



#### STEP 4 COMPLETE




PAGE 4 OF 5

COASTERFURNITURE.COM



Product Size: 330 X 381 X 610 H (MM)

Product Size: 13" X 15" X 24"



Note: Dimension tolerance ±5%