


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

950031
Shoe Rack

REVISION 0: 12/01/2018
REVISION 1: 09/10/2020

ITEM:950031

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION

A SIDE FRAME



2PCS

B SHELF



4PCS

HARDWARE IDENTIFICATION

1 BOLTS

M6*30mm



16PCS

2 ALLEN WRENCH

4mm




1PC


ITEM: 950031

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2



ITEM: 950031

ASSEMBLY INSTRUCTIONS



Note : Dimension tolerance $\pm 5\%$