









Assembly Instructions

Item No :53448

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

(Note: Loosely thread all screws/bolts first. Once the item is assembled then completely tighten.)

Parts List				Hardware List			
No.	Description	Sketch	Qty	No.	Description	Sketch	Qty
A	Left Leg		1	A	1" Bolt		30
B	Right Leg		1	B	1" Lock Washer		30
C	Shelves (A to E)		5	C	Spring Washer		30
				D	Allen Wrench		1



Unwrap the box and place both Legs Left (Point A) & Right (Point B) vertical on the floor.

Fix the top shelf (No. A) on the top of both legs above the support as shown in image.

