


ASSEMBLY INSTRUCTIONS

Components and Hardware List for SKU No. 58111





Desk (1 pc)		Legs (2 pcs)		Wooden Strip (1 pc)
small Bolt	long Bolt	Washer	Spring washer	Allen key
∅ 0.24*1.38" (8 pcs)	∅ 0.24*2" (2 pcs)	∅ 0.31" (8 pcs)	∅ 0.31" (8 pcs)	0.16" (1 pc)
Extra = 1 pc	Extra = 1 pc	Extra = 1 pc	Extra = 1 pc	


Instructions to Assembly

- Carefully remove all parts from the carton. Lay them out on a clean soft surface.
(Do not discard any packing materials until the product is fully assembled, to prevent any small parts from being accidentally discarded.)
- Lay the Desk upside down on a clean soft surface or fabric . (Pic.1)
- Take each leg set and match it with the corresponding letter.
Align the set's screw holes with the desk's screw holes. (Pic.2)
- Place spring washer & flat washer before inserting the small bolt into the holes.
Tighten each bolt by provided Allen key. (Pic.3)
- After securing the legs set, align the strip's screw holes with the leg's screw holes. (Pic.4)
- Inserting the long bolt into the holes. Tighten each bolt by provided Allen key. (Pic.5)
- After securing the legs set, carefully turn the desk upright onto its legs. (Pic.6)


(Pic.5)




Pic. 1



Pic.2



Pic.4



Pic.5



Pic.6

Usage Instructions:

- Clean your furniture regularly with dry cloth and any good quality furniture wax.
- Use trays or coasters to prevent heat marks from occurring on the furniture .
- Avoid keeping your furniture next to windows and other places directly exposed to sunlight to prevent its color fading.
- Wipe off any excess water or spilled liquid immediately to prevent water marks.