

ASSEMBLY INSTRUCTION

MODEL: MB-B032

HARDWARE LIST

NO	QTY
Ⓐ	1Pc
Ⓑ	1Pc
Ⓒ	1Pc
Ⓓ	1Pc
Ⓔ	1Pc
Ⓕ	2Pcs
Ⓖ	1Pc
Ⓗ	4Pcs
Ⓘ	1Pc
Ⓝ	32Pcs
Ⓚ	32Pcs
Ⓛ	4Pcs
Ⓜ	1Pc

