


MODEL#


CM-BK029TS

Questions?

GIVE US A CALL: 1-888-980-5122 MON – FRI 8:30AM – 5:30PM (PT)



TOOLS REQUIRED





3 - People Recommended

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday - Friday 8:30 AM- 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instruction readily available, along with your order receipt.



Are you missing anything?	Check out our Quick Tips!	
Double-check all parts, hardware and accessories listed on Page5 are accounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!	
Should we send any replacements?	Prep Time!	
Are there any irregularities or flaws in the parts? We can send replacements!	Please review the assembly instructions and all diagrams prior to assembling.	

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.






Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

BUNKBED CM-BK029TS






PARTS



HARDWARE




Wrench 14mm


(White)


Wrench 13mm

(White)





Hook the top of the ladder (#10) and align the bottom, then secure by using bolts (#C) with washers (#J). Part #10 x1pc Hardware#© x4pcs Hardware (#J) x4pcs #J Hardware (#O) x1pc #10 #J #9 Part #9 x3pcs Hardware #A x12pcs #9 Hardware #J x12pcs #9 Hardware#0x1pc **Ğ**#J Place the base frames (#9) onto the top bed, then secure by using bolts (#A) with washers (#J).








9











ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all boits and/or screws are properly tightened and secured.

√ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

Safety Warnings

- 1.Follow the information on the warnings appearing on the upper bunk end structure and on the carton. Do not remove warning label from bed.
- 2.Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.
- 3. Surface of mattress must be at least 5 in. (127mm) below the upper edge of guardrails.
 - 4.Do not allow children under 6 years of age to use the upper bunk.
- 5.Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
- 6.Do not allow horseplay on or under the bed and prohibit jumping on the bed.
 - 7. Always use the ladder for entering and leaving the upper bunk.
- 8.Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
- 9.Use of a night light may provide added safety precaution for a child using the upper bunk.
- 10. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
 - 11. The use of water or sleep flotatio mattresses is prohibited.
 - 12. Keep these instructions for future reference.
- 13.Use only mattress which is $(74"-75")X(37\frac{1}{2}"-38\frac{1}{2}")X6"$ on upper bunk and for bottom bunk required (74"-75")X(53"-54")X10" mattress.
 - 14. Prohibit more than one person on upper bunk.
 - 15. Maximum total weight is not to exceed 400 lbs. on the upper bunk.

STRANGULATION HAZARD:

Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts and jump ropes.