


MODEL#

CM-CR150

Questions?

GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)



TOOLS REQUIRED



Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



2 - People Recommended

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline Toll-Free 1-888-980-5122



WEBSITE www.foagroup.com











Monday to Friday 8:30AM- 5:30PM (PT)



E-MAIL cs.ec@foagroup.com



FurnitureOfAmerica



Double-	check all parts, hardware and bries listed are all acccounted for.	Check out our Quick Tips! We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Are ther	d we send any replacements? The any irregularities or flaws in the law was a send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS


Note:

Every cam lock bolt must have a cam lock connector in order to fasten the parts together.







olt cam lock screwdriver




Screw the cam bolt into panel.



Insert the cam bolt into the bolt hole of joint panel.



Align the cam lock with its side opening (or arrow) pointing to cam bolt.




Turn the cam lock clockwise gently until it will not turn any more.

CURIO CABINET

CM-CR150



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS






#31pc











Top Panel

Bottom Panel

Front Panel

Back Panel

















Crossbar

Door-Up

Door-Down


Shelf Glass

CURIO CABINET

CM-CR150



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



HARDWARE





Bolt 1/4" x 1-1/8"





U Support-Up





Magnet





Screw 3 x 16mm



Plastic Line

(#B) 14pcs



Flat Washer 1/4" x 13mm





U Support-Down



Shelf Support





_.g...



(#R) 1pc

Large Screw

#C) 2pcs



CAM-Bolt





Push Metal





Wood Dowel Ø8 x 30mm





Plastic



Short Screw





CAM-Lock






T Plastic













L Metal



CM-CR150 is packed in 2 cases

Carton	Disignation	Part		Hardware(CM-CR150-2 INSIDE)	
	Front Panel	#3			#A x 14pcs
					#B x 14pcs
	Back Panel	#4	☆		#C x 2pcs
					#D x 2pcs
CM-CR150-1			*		#E x 4pcs
	Door-Up (2pcs)	#6	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		#F x 4pcs
					#G x 4pcs
	Door-Down	#7		8	#H x 8pcs
					#I x 4pcs
	Top Panel	#1			#J x 16pcs
					#K x 8pcs
					#L x 1pc
	Bottom Panel	#2		ALIMAN)	#M x 18pcs
					#N x 1pc
CM-CR150-2					#O x 1pc
	Crossbar(2pcs)	#5			#P x 2pc
					#Q x 1pc
	Shelf Glass(4pcs)	#8			#R x 1pc
					#S x 1pc

1



2

Part #5 x2pcs


Hardware#A x 3pcs

Hardware #B x 3pcs

Hardware#Lx1pc

Hardware#D x 2pcs

Hardware#K x 4pcs




3

Part #2 x1pc

Hardware#A x 3pcs

Hardware#B x 3pcs

Hardware#Lx1pc



4


Part #4 x1pc


Hardware#A x 8pcs


Hardware#B x 8pcs

Hardware#Lx1pc

Hardware#K x4pcs








8

Hardware (#) x 1pc Hardware (#P) x 2pcs

Hardware (#O) x1pc

Hardware#R x 1pc

Hardware#S x 1pc



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!


To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

Wall Mounting and Fixing



EXPANSION WALL ANCHOR

Our provided expansion wall anchors are only suitable for masonry walls, such as drywall, plaster or concrete, and are best for holding lightweight items or for anti-tip prevention. If you are unsure of the correct wall anchor to use with the product, please request professional guidance. Liability for product damage or failure due to using the incorrect anchors will fall on the installer.




CHECK BEFORE PROCEEDING

Prior to drilling or hammering, please check for wires or pipes. We recommend using a stud finder to locate a stud, which will offer more appropriate resistance and hold more weight.

QUICK TIPS


1.If unsure of the proper size, always choose a larger screw and wall anchor.






2. Match the drill bit to the wall anchor and hole size.

3. Only drill horizontally. Do not force the drill or enlarge the hole for the wall anchor.





4. Take extra care when drilling into high walls or ceramic tiles. Wall anchors should be a tight fit for the hole. Never use wall anchors in ceilings.





We recommend a yearly check to see if the wall anchor or screw has loosened. If so, please remove the existing wall anchor and screw, and use a new anchor.