

MODEL#


CM6853

Questions?

GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED

No Tools Required For Assembly





2 - People Recommended

ASSEMBLY RATING



EASY ----- DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 21-12-07





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline Toll-Free 1-888-980-5122



WEBSITE www.foagroup.com



Monday to Friday 8:30AM- 5:30PM (PT)



E-MAIL cs.ec@foagroup.com











FurnitureOfAmerica



Are you missing anything? Double-check all parts, hardware and accessories listed are all acccounted for.	Check out our Quick Tips! We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements?	Prep Time!
Are there any irregularities or flaws in the parts? We can send replacements!	Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

SOFA CM6853



- · Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS







(#3) 1pc










Chaise Seat

Chaise **Back Cushion**











Console **Back Cushion**





(#5) 1pc

Recliner Armless Chair Seat

Recliner Armless Chair Back Cushion

Corner Seat



Corner Left **Back Cushion**





(#10) 1pc







Corner Right **Back Cushion**

Armless Chair Seat

Armless Chair Back Cushion Right Chair Seat





Right Chair **Back Cushion**


HARDWARE





Knob Screws

Exploded View




CM6853 is packed in 6 case

ITEM NO	DESCRIPTION	PARTS		HADRWARE
	Chaise Seat	#1		
CM6853-LCE	Chaise Back Cushion	#2		
0110050 07	Console Seat	#3		#A x2pcs
CM6853-CT	Console Back Cushion	#4		
CM6853-RCH	Recliner Armless Chair Seat	#5		
CIVIOUSS-IXCIT	Recliner Armless Chair Back Cushion	#6		
	Corner Seat	#7		
CM6853-CNR	Corner Left Back Cushion	#8		
	Corner Right Back Cushion	#9		
CM6853-CH	Armless Chair Seat	#10		
31410033-011	Armless Chair Back Cushion	#11		
	Right Chair Seat	#12		
CM6853-RAC	Right Chair Back Cushion	#13		

1 Part #1









3

Part #3 x1pc
Part #4 x1pc



4


Hardware #A x 2pcs





5


Part #5 x1pc

Part #6 x1pc











9

Part#10 x1pc

Part#11 x1pc







11


Part #12 x1pc

Part #13 x1pc






13



14



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

√ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.