





Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

Parts key			
No	Code	Q'ty	Description
1	1700-5020P51	1 Pc	Storage Box
2	1700-5020P02	4 Pcs	Leg
3	1700-5020P05	3 Pcs	Drawer Complete
4	1700-5020P06	3 Pcs	Drawer Glide
5	1700P01F	4 Pcs	Floor Glide
6	1700P04	3 Pcs	Drawer Pull w/ Screw
7	1700-5020P22	1 Pc	Lift Top
8	1700-5020P22H	2 Pcs	Lift Top Hinge
9	1700P01E	1 Pc	Electric Outlet

Hardware Kit 1700-5020P01		
No	Description	Q'ty
A	 Hexa Nut Ø8	8 pcs
B	 Lock Washer Ø8.5	8 pcs
C	 Flat Washer Ø8.5	8 pcs
D	 Key Wrench	1 pc

### STEP 1:

-Carefully lay the Storage box upside down on a smooth flat surface to prevent scratches.

-Affix each Leg to each corner of the Table Top as shown in illustration. Insert a Flat Washer, Lock Washer and Nut on the bolts of each Leg (See Detail A)

Once all Legs are in place, fully tighten nuts by turning clockwise using provided Key Wrench until secure.

- Carefully turn Desk W-power upright.

