



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

Parts key							
No	Code	Qty	Description	No	Code	Qty	Description
1	1852-70P51	1 pc	Storage Box	5	1852-70P08	3 psc	Shelf
2	1852-70P07	2 pcs	Sliding Door	6	1852P01F	4 pcs	Floor Glide
3	1852P04	2 sets	Pull w/Screws	7	1852P01L	1 pc	Floor Leveler
4	1852P07S	4 sets	Sliding Wheel & Lock w/Screws - 2 pcs				



TO REACTIVATE DOOR PIN, PRESS THE BUTTON WHEN IN THE BOTTOM POSITION



TO RELEASE DOOR PIN, MOVE THE BUTTON TO THE BOTTOM POSITION

