



Parts List			
ITEM	Code	Description	Qty
A	BRYSONP41BLUE	Cushion complete	1pc
B	BRYSONP02F	Front legs	2pcs
C	BRYSONP02R	Rear legs	2pcs
D	BRYSONP02W	Plastic washers	4pcs



Assembly Steps:

- Step 1. Turn chair (A) over on a clean flat surface.
- Step 2. Remove legs from zippered pocket . at the bottom of the chair.
- Step 3. Install Front Legs (B) and plastic washer (D , optional) to the proper position .
- Step 4. Install Rear Legs (C) and plastic washer (D , optional) to the proper position.
- Step 5. Turn chair to its upright position .

Please note:

1. The legs tapered faces are toward inside.
2. To level chair you may need to add or remove plastic washers (D) from the legs.

Fabric maintenance:

Avoid direct sunlight, water, oil, acid, sharp object etc. Use vacuum cleaner to clean. Clean only with water-based shampoo or foam upholstery cleaner. Do not over wet. Do not use solvents to spot clean. Pile fabrics may require brushing to restore appearance. Cushion covers should not be removed and laundered.

Fabric content: 100% polyester.

Cleaning code: W