

## **ASSEMBLY INSTRUCTIONS &** PARTS IDENTIFICATION **BRYSON-CH-OAT**

| Parts List |              |                  |      |
|------------|--------------|------------------|------|
| ITEM       | Code         | Description      | Qty  |
| Α          | BRYSONP41OAT | Cushion complete | 1pc  |
| В          | BRYSONP02F   | Front legs       | 2pcs |
| С          | BRYSONP02R   | Rear legs        | 2pcs |
| D          | BRYSONP02W   | Plastic washers  | 4pcs |











A.Chair with Reversible B. Front legs **Seat Cushion** 


with 5/16"

C. Rear legs with 5/16" bolt

D. Plastic Washers







Step 1. Turn chair (A) over on a clean flat surface.

Step 2. Remove legs from zippered pocket.

at the bottom of the chair.

Step 3. Install Front Legs (B) and plastic

washer(D,optional) to the proper position .

Step 4. Install Rear Legs (C) and plastic washer(D,optional) to the proper position.

Step 5. Turn chair to its upright position.

## Please note:

1. The legs tapered faces are toward inside.

2.To level chair you may need to add or remove plastic washers (D) from the legs.

## Fabric maintenance:

Avoid direct sunlight, water, oil, acid, sharp object etc. Use vacuum cleaner to clean. Clean only with water-based shampoo or foam upholstery cleaner. Do not over wet. Do not use solvents to spot clean. Pile fabrics may require brushing to restore appearance. Cushion covers should not be removed and laundered.

Fabric content: 100% polyester.

Cleaning code: W

Made in Vietnam