




### PARTS LIST

| Object | Code           | Description    | Quantity |
|--------|----------------|----------------|----------|
| A      | LACROIXP41NAVY | Cushion        | 1pcs     |
| B      | LACROIXP42     | Front Leg      | 2pcs     |
| C      | LACROIXP42R    | Rear Leg       | 2pcs     |
| D      | LACROIXP01F    | Floor Glide    | 4pcs     |
| E      | LACROIXP01W    | Plastic Washer | 4pcs     |



### Assembly Steps



- Step 1. Turn chair over on a clean flat surface
- Step 2 Remove chair legs (item B & C) from zippered pocket at chair bottom
- Step 3 Place plastic washer ( item E ) onto the bolt on each leg

- Step 4. Install the leg (item B & C) to the chair
- Step 5 Turn chair to its upright position

\*\*\* Please note : To level chair you may need to add or remove washers from the particular legs

#### FABRIC CARE INSTRUCTIONS

##### REGULAR CARE - CLEANING CODE W

- Spot clean only with water based shampoo or foam upholstery cleaner. Pretest a small, inconspicuous area. Do not over wet. Do not use solvents. Pile fabrics may require brushing with a non-metallic, stiff bristle brush to restore appearance. Hot water extraction or steam cleaning is not recommended. Cushion covers should not be removed and laundered.

- To prevent overall soiling, frequent vacuuming or light brushing with a non-metallic, stiff bristle brush to remove dust and grime is recommended. When cleaning a spill, blot immediately. Clean spots or stains from the outside to the middle of the affected area to prevent circling. Use a professional furniture cleaning service when an overall soiled condition has been reached.

#### FABRIC CONTENT:

83% POLYESTER,10% ACRYLIC,7% LINEN