





Parts List			
Item	Code	Description	Qty
A	THEOP41GOLD	Seat cushion	1pc
B	THEOP42	Front legs	2pcs
C	THEOP42R	Rear legs	2pcs
D	THEOP01W	Plastic washers	4pcs



Assembly Steps:

- Step 1. Turn chair body over on a clean flat surface.
 - Step 2. Remove legs from zippered pocket underneath chair.
 - Step 3. Place plastic washer (Item D) on the bolt on each leg.
 - Step 4. Screw in front legs (item B) until they are hand tight.
 - Step 5. Screw in rear legs (item C) until they are hand tight and in an outward position.
 - Step 6. Turn chair to its upright position.
 - Step 7. Put seat cushion (Item A) complete upon the chair
- ***Please note: To level chair you may need to add or remove washers from the appropriate legs.

FABRIC CONTENT

***Fabric: 100% polyester

***Cleaning Code: S

Professional cleaning recommended. Spot clean with a mild water-free solvent or dry cleaning product. Vacuum surface occasionally with an upholstery attachment. Avoid direct sunlight, water, oil, acid, sharp object etc. Do not clean with water or any harsh detergents.