ASSEMBLY INSTRUCTIONS 1561,1562-140 SIDE CHAIR WISHBONE BACK W WOOD SEAT



Thank you for purchasing this quality product. Before beginning, please check the packing material carefully for small parts which may have come loose inside the carton during shipping. Please do not discard any packing material until all parts have been located. If any parts are missing, please contact your dealer for prompt replacement.

Caution: (1) These parts are cumbersome and heavy. This product can best be assembled with the assistance of one or more persons in order to prevent personal injury and to ensure parts are not damaged during the assembly process. If dirty, clean finished parts with mild dishwashing liquid and water solution applied on damp cloth. Cloth should not be excessively wet. Polish finish with soft cloth and an industry recognized furniture polish.


(2) To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residue and rough surfaces and also check for staples or nails left after removing the packaging material. The manufacturer will not be held responsible if preventative steps are not taken prior to installation.

(3) During normal use every day, screws, bolts, nuts and wooden plugs may loosen up. They should be periodically inspected and retightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the below mentioned components are attached to the furniture properly and kept tightened.

Parts & Hardware List:

NO	PARTS LIST	QTY.
A	SEAT PANEL WITH WOOD FRAME	1 PC
В	CHAIR BACK FRAME	1 PC
С	LEG	2 PCS

NO.	HARDWARE LIST		QTY.	NO.	HARDWARE LIST		QTY.
#1	HEX HEAD BOLT		4 PCS	#2	HEX HEAD BOLT		6 PCS
		3"L X 5/16"				2"L X 5/16"	
#3	LOCK WASHER		10 PCS #4	FLAT WASHER		10 PCS	
		5/16"				5/16" X 23 mm	
#5	OPWN WRENCH		1 PC				_
		12 mm					



Assembly Procedures:

Tools required: Wrench #5 (see hardware list).

**Note: First read the chair leveling instructions. This is an additional assembly sheet found inside the carton.

Chair Leveling Instruction:

Do not tighten all the bolts until the has been put on a flat surface to adjust & level all the legs so that they do not wobble. Once adjusted then tighten all the bolts. Do not over tighten.

- Step 1: Lay out all parts and hardware on a clean protective surface to protect the furniture and the floor during assembly. Make sure the quantity
- of each is correct and all parts are free of stains, staples, screws, and nails.

 Step 2: Remove the plastic cover on the seat panel with wood frame and assemble the seta panel (A) to the back frame (B) using hardware (#1, #3, #4, #5) and (#2, #3, #4, #5) as shown.

 Step 3: Assemble the leg (C) to the seat panel (A) using hardware (#2, #3, #4, #5) as shown.

Assembly is complete.