

Part # TB-FUJI4728 XX

TB-FUJI4728-21-0916

**PARTS**

**A** x2  
**B**  
**C** x2  
**D** x2  
**E** x8 M8 40mm  
**F** x4 M6 45mm  
**G** x4 M6 10mm  
**H**  
**I**

**1**

Diagram showing the table top (B) being attached to the side rails (A) using screws (E) and brackets (C). Screws (F) are used to secure the brackets (C) to the side rails (A).

**2**

Diagram showing the back rail (D) being attached to the side rails (A) using screws (E) and brackets (H). A callout shows a close-up of the bracket (H) and screw (E) connection with the instruction: **80%** Tighten Part E.

**3**

Flip Table

**100%** Tighten Part E

Diagram showing the table top (B) being flipped to the underside and the front rail (D) being attached to the side rails (A) using screws (E) and brackets (G, H). A callout shows a close-up of the bracket (H) and screw (E) connection with the instruction: **100%** Tighten Part E.

**4**

Diagram showing the final assembled table.