MANHATTAN COMFORT

ASSEMBLY INSTRUCTIONS



COD: 15300

REV. 00

IMPORTANT REMARKS

Never climb or lean on the furniture. You may suffer serious accidents.



Use the packaging to cover the assembly area and separate all parts.



Indentify the parts by observing the number printed on their edges.



CARE INSTRUCTIONS

Wipe clean using a damp cloth and a mild cleaner. Do not use abrasive and chemical products.

HANDLING



Move the piece carefully, don't drag it. Ask for someone else's help to do so.

HARDWARE

Identify and separate the hardware used in the assembly. There's a label on each package identifying the parts and where to use them.



COD.1533-12x

A

COD.0329-34x

B

COD.2661-2x

C

COD.3527-11x



D

COD.0342-14x

E

COD.6533-8x



F

COD.0599-9x

G

COD.0494-9x

H

STICKER-6x



I

COD.1861-32x

J

COD.1668-16x

K

COD.9058-4x

L

COD.0338-4x

M

COD.7531-2x

N

COD.0357-50x

O

COD.3283-5x

P

COD.3284-3x



Q



DESCRIPTION

W:85,43 inches H:20,86 inches D:17,59 inches
L:2170mm A:530mm P:447mm



CÓD:15300			
PART	QUANTITY	DESCRIPTION	BOX
01	01	TOP BOARD	01
02	01	BASE	01
03	01	LEFT SIDE	02
04	01	RIGHT SIDE	02
05	01	LEFT INNER SIDE	02
06	01	RIGHT INNER SIDE	02
07	01	CENTER SHELF	02
08	01	LOWER DIVISION	02
09	01	UPPER DIVISION	02
16	02	SIDE BACKPLATE	01
17	01	UPPER BACKPLATE	01
18	01	LOWER BACKPLATE	01
22	02	SIDE SHELF	02
24	01	LEFT DRAWER FRONT	02
25	01	RIGHT DRAWER FRONT	02
26	04	DRAWER SIDE	02
27	04	DRAWER BACK PANEL	02
28	02	DRAWER BOTTOM	02







20Kg = 44Lb
5Kg = 11Lb

COD. 1533 A	COD. 0329 B	COD. 2661 C	COD. 0599 G	COD. 0494 H	COD. 1861 J	COD. 9058 L	COD. 7531 N	COD. 3283 P	COD. 3284 Q

01



02





COD. 0329 B	COD. 0329 D	COD. 0599 G	COD. 0494 H	STICKER I
				

03



04







COD. 1533	COD. 2661	COD. 3527	COD. 1668	COD. 1668	COD. 0338	COD. 0357
A	C	D	E	K	M	O

05



06





COD. 6533
F

07







08