


ASSEMBLY INSTRUCTIONS

SKU - #604 Corner+Armless chair

meridian.
furniture



+ Do Not Use Power Tools



+ Suggested Adults



NOTE: For questions about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455.

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

- part # - Corner base
- part # - Corner cushion
- part # - Armless chair base
- part # - Armless chair cushion
- part # - Chrome leg
- part # - Gold leg

Do not assemble if any of the following Hardware parts are missing:

- part # - Allen wrench
- part # - Bolt M8"*35mm
- part # - Washer M8*16mm
- part # - Connect metal plate


2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Parts Included



① Corner base
1pc

② Corner cushion
1pc





③ Armless chair base
1pc

④ Armless chair cushion
1pc



⑤ Chrome leg
8 pcs

⑥ Gold leg
8 pcs



+ Hardware Included


A Allen wrench
1 pc

B Bolt M8"*35mm
24pcs



C Washer M8*16mm
24 pcs

D Connect metal plate
100*75*18mm
2 pcs



ASSEMBLY INSTRUCTIONS

SKU - #604 Corner+Armless chair

