








PARTS LIST

NO	COMPONENT	SKETCH	QTY
A	SOFA		1 PC
B	WOODEN LEG H175mm		4 PCS
C	CENTER SUPPORT LEG		1 PC

HARDWARE LIST

NO	COMPONENT	SKETCH	QTY
1	PLASTIC WASHER D47mm		5 PCS

To assemble the sofa, please follow the following steps but do not tighten all bolts:



Sofa (A)

Step 1 :

Take the parts out from zipper pouch of bottom product.


Step 2 :

Tighten wooden leg (B) with plastic washer (1) by turning it clockwise direction. Repeat the same method until all wooden leg (B) been assembled.

Step 3 :

For the center leg, there is hole at the center on the bottom of sofa. Please put the center leg (C) together with plastic washer (1), tighten up the center leg by turn it clockwise.

Completed



FOR LEATHER and P.U Cleaning (Code "X")

Clean by lightly brushing and vacuuming only to remove dust and particles buildup. Water -based foam cleaner or solvent based cleaning agents of any kind may cause excessive shrinking, staining or distortion of the surface pile and, therefore, should not be used.

FOR FABRIC Cleaning (Code "WW")

Use water-based agents only.
Do not use solvents.
Gently remove stains by blotting or hang washing.
Do not use excessive brushing or rubbing.