



Assembly Instructions

ITEM: Y2264-410 - SEVILLA 4/6 F HEADBOARD
Y2264-428 - SEVILLA 4/6 F STORAGE FOOTBOARD & SLATS
Y2264-530 - SEVILLA 3/3-4/6 T/F SIDERAILS


STEP 2



STEP 3



STEP 4



STEP 5

