

ASSEMBLY INSTRUCTIONS

DC506

A x1	B x1	C x1	D x1	E x5	F x4	G x1
						

