















# Assembly Instruction

## Item NO:PRO#460H/461D

NO	Description	Sketch	Q'TY	NO	Description	Sketch	Q'TY
A	Allen Wrench 4mm		1	I	Bolt Ø1/4**1-5/8"		2
B	Touch up Pen		2	J	Decoration Bolt Cap		2
C	Allen Wrench 2.5mm		1	K	Allen Wrench 4mm For Electric Drill		1
D	Ladder Rail Coupler		1	L	Connector Bolt Ø2.5mm		2
E	Ladder Rail Finial		2	M	Wire buckle		2
F	Wall Strap		1	N	Screw M6*3/8"		2
G	Connector Bolt Ø1/4**1"		4				
H	Connector Cap Ø1/4**5/8"		4				

**Diagram 4**

4. Carefully place Hutch on top of Desk,aligning rear corners.Looseen screw on coupling plate found on the back of Hutch,rotate 90°clockwise,retighten screw.Using Screw I ,secure coupling plate to rear of Desk Top as shown above.

