


ASSEMBLY INSTRUCTION

Item No:D829-69

Description: DINING BENCH







IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.

Each chair

PARTS LIST		
NO.	DESCRIPTION	QTY.
1	BENCH SEAT	1 PC
2	BENCH LEG	4 PCS

HARDWARE LIST		
NO.	DESCRIPTION	QTY.
A	ALLEN KEY M4 X 63 MM 	1 PC
B	JCBC BOLT M6 X 60 MM 	8 PCS
C	SPRING WASHER 1/4" 	8 PCS
D	FLAT WASHER 1/4" 	8 PCS

STEP 1

