
Progressive® ASSEMBLY INSTRUCTION Item No. D828 15

Item No: D838-15

Description: ROUND DINING TABLE




IMPORTANT NOTE:

- .Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- .Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- .Do not tighten all screws/bolts until all completely assembled.
- .Keep all hardware parts out of reach of children.


PARTS LIST			
NO.	COMPONENT	QTY.	
1	TABLE TOP	1 PCS	
2	TABLE LEG	4 PCS	

HARDWARE LIST			
NO.	COMPONENT	QTY.	
A	HEX BOLT - 5/16" x 2 1/2 "	8 PCS	
В	SPRING WASHER - 5/16"	8 PCS	
C	FLAT WASHER - 5/16"	8 PCS	
D	ALLEN WRENCH- 12.8MM	1 PCS	

STEP 1



STEP 2



MADE IN MALAYSIA 20170630