








ASSEMBLY INSTRUCTIONS
ITEM # : 30036
JUNIPER ACCENT CASE

JUNIPER ACCENT CASE HARDWARE

 <p>A</p> <p>LEG x 4</p>	 <p>B</p> <p>LEG x 4</p>	 <p>C</p> <p>ALLEN BOLT x 8 (Ø5/16" *40 MM)</p>
 <p>D</p> <p>SPRING WASHER x 8 (Ø5/16")</p>	 <p>E</p> <p>FLAT WASHER x 8 (Ø5/16")</p>	 <p>F</p> <p>ALLEN KEY x 1 (M4)</p>
 <p>G</p> <p>TIPPING RESTRAINT x1</p>		

Customer Service Contact Information:
 Toll Free Phone Number: 1-844-771-2727
 Email: consumercare@lanefurniture.com
 Website: www.lanefurniture.com

- NOTES :**
- CHECK CAREFULLY FOR SMALL PARTS WHICH MAY COME LOOSE DURING SHIPMENT.
 - REMOVE ALL COMPONENTS FROM THE PACK AND PLACE ON A CLEAN, SOFT SURFACE TO ASSEMBLE.
 - UNITS SHOULD BE ASSEMBLED BY TWO OR MORE PEOPLE.
 - DO NOT OVER - TIGHTEN SCREW/ BOLTS UNTIL ASSEMBLY IS COMPLETED.
 - WITH USE, SCREW/ BOLT MAY BE COME LOOSE & MUST BE TIGHTENED PERIODICALLY.



STEP 1 (x1)

