

PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS

ITEM NO. / ARTICLE NO. / ARTICULO NO : P301676

DESCRIPTION/LA DESCRIPCION/DESCRIPCIÓN :Entertainment Console/
Console de divertissement murale/Consola de entretenimiento



A *

x2 Adjustable Shelf
x2 Tablette ajustable
x2 Estante ajustable





B *

x4 Adjustable leveler-White
x4 Patin réglable
x4 Nivelador ajustable



C *

x1 Tipping restraint
x1 Liste des pièces de
quincaillerie antibasculement
x1 Abrazadera antivuelco



D *



x8 Shelf Supports
x8 Supports Pour Tablette
x8 Soporte De Las Repisas

* Replaceable Part

ASSEMBLY INSTRUCTIONS/ NOTICE DE MONTAGE/ INSTRUCCIONES DE MONTAJE

ITEM NO. / ARTICLE NO. / ARTICULO NO : P301676

DESCRIPTION/LA DESCRIPCION/DESCRIPCIÓN :Entertainment Console/
Console de divertissement murale/Consola de entretenimiento



* Replaceable Part

REPLACEABLE PART/ PARTIE REMPLACABLE/ PARTE REEMPLAZABLE

ITEM NO. / ARTICLE NO. / ARTICULO NO : P301676


DESCRIPTION/LA DESCRIPCION/DESCRIPCIÓN :Entertainment Console/
Console de divertissement murale/Consola de entretenimiento





- A** * RP301676-SHELF
x2 Adjustable Shelf
x2 Tablette ajustable
x2 Estante ajustable




- B** * RC-FG-WHITE
x4 Adjustable leveler-White
x4 Patin réglable
x4 Nivelador ajustable




- C** * RC-ANTI-TIP
x1 Tipping restraint
x1 Liste des pièces de quincaillerie antibasculement
x1 Abrazadera antivuelco




- D** * RP301676-SUPP
x8 Shelf Supports
x8 Supports Pour Tablette
x8 Soporte De Las Repisas



- * RP301676-HINGE
* x8 Door Hinge
* x8 Charnière de porte
* x8 Bisagra de la puerta



- * RP301676-CATCH
* x8 Door Catch
* x8 Catch de aimant
* x8 Captura de imá



- RP301676-PULL
* x4 Pull with screw
* x4 Tirer et vis
* x4 Tire y Tornillo



- * RP301676-GRO
x2 Grommet
x2 Oeillet
x2 Ojal

* Replaceable Part