

# HH-8750 Dining Table

## ASSEMBLY INSTRUCTIONS

### TECHNICAL SPECIFICATION

SKU: HH-8750-078

DESCRIPTION: Dining Table 78"x40"x30"

### Important safety instructions:

- \* Please carefully read all instructions before assembling.
- \* For your safety, assembly by two or more adults is recommended.
- \* Keep instructions for future use.

### Pre-assembly:

- \* Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts of hardware.
- \* Remove parts and hardware from box along with any plastic protective packaging.

### Parts :

- \* Wood Top
- \* 4 Wood Legs


### Hardware :

- \* 8 Bolts
- \* 8 Washers

### TO ATTACH THE LEGS TO THE TABLE

NOTE: ENLIST ADDITIONAL HELP FOR THE PROCESS OF ASSEMBLY.

- 1 TURN THE TOP UPSIDE DOWN OVER A CLEAN SURFACE.
- 2 ALIGN THE 4 LEGS TO TABLE TOP.
- 3 ATTACH THE 4 LEGS TO TABLE TOP WITH THE HARDWARE BOLTS AS SHOWN.
- 4 TURN THE TABLE BACK OVER CAREFULLY.



[www.sunsettrading.com](http://www.sunsettrading.com)

[info@sunsettrading.com](mailto:info@sunsettrading.com)

603-421-0900