Parker House
FURNITURE

Assembly Instruction

Item No: CAT#486A / CAT#486B

Description : DESK TOP / DESK PEDESTALS

Rev 2 :2021-11-11

FRONT



BACK



Parker House
FURNITURE

Assembly Instruction

Item No: CAT#486A / CAT#486B

Description : DESK TOP / DESK PEDESTALS

Rev 2 :2021-11-11

HARDWARE LIST

No	Description	Sketch	Q'TY
A	Allen wrench 4mm		1PC
B	Bolt Ø 1/4"x1-1/4"		8PCS
C	Lock washer		8PCS
D	Flat washer		8PCS
E	Grommet		2PCS
F	Allen wrench 4mm		1PC
G	Head screw		4PCS
H	2 port USB		1PC
I	File rods 320x3x12mm		2PCS

PARTS LIST

CAT#486A DESK TOP

TABLE TOP (1PC)

①



CAT#486B DESK PEDESTALS

LEFT PEDESTAL (1PC)	RIGHT PEDESTAL (1PC)
②	③ 

File rods and hardware pack is screwed here



Parker House
FURNITURE

Assembly Instruction

Item No: CAT#486A / CAT#486B

Description : DESK TOP / DESK PEDESTALS

Rev 2 :2021-11-11

To connect the desk top, you will need to detach the top drawer of the left pedestal. To remove the drawers, press on the levers located on both sides of the drawer simultaneously while pulling the drawer out.

STEP 2



Insert wire grommets (E) into wire hole on desk's top.

STEP 3



Place the desk top on the left and right pedestal lining up the dowels and bolt holes. once aligned, secure the top using the bolt (B), lock washers (C), and flat washers (D) as shown in the diagram.



Electric drill

Parker House
FURNITURE

Assembly Instruction

Item No: CAT#486A / CAT#486B

Description : DESK TOP / DESK PEDESTALS

Rev 2 :2021-11-11

STEP 4

Mount the 2 port USB at the desired place with screw(G).



Open the pullout drawer, take off the handle & knobs installed on the back of drawer front and reattach the handle on the front side as shown.

STEP 5



Assembled leveler = 8PCS