



# SW 8068 - F / Q / K




Attach the headboard post (P1) to the headboard (P2). You will need to use hardware :

- A = 4pcs
- C = 4pcs
- D = 4pcs
- E = 20pcs




Attach the headboard (P2) using hardware :  
G = 5pcs



Attach the side rail (P3) to the headboard (P2) and footboard (P4) using hardware :


- A = 8pcs
- C = 8pcs
- D = 8pcs
- E = 4pcs



Fix the adjuster (F) to the support leg (P6) using hardware :  
F = 2pcs

Attach the support legs (P6) to the centre rail (P5) using hardware :  
B = 2pcs

Attach the centre rail (P5) to the headboard (P2) and footboard (P4) using hardware :  
G = 2pcs




Lay the slats (P7) between the side rail (P3) using hardware :  
G = 28pcs (F)  
or  
G = 30pcs (Q/K)

Attach the slats (P7) to the centre rail (P5) using hardware :  
G = 3pcs


## WARNING!!

- Remove hardware from box and sort by size.
- Please check to see that hardware and parts are present prior start of assembly.
- Please follow attached instruction in the same sequence numbered to ensure fast and easy assembly.
- Do not use this bed if any part is broken, torn or missing.
- The assembly of this product requires two people.
- Do not use any power tools as this may damage the frame and will invalidate any claim.

## PART LIST

P1		Headboard Post = 2pcs
P2		Headboard = 1pcs
P3		Side Rail = 2pcs
P4		Footboard = 1pcs
P5		Centre Rail = 1pcs
P6		Support leg = 2pcs
P7		Bed Slats (F) = 14pcs Bed Slats (Q/K) = 15pcs

## HARDWARE LIST

A		M6 x 90mm JCBC	12pcs
B		M6 x 50mm JCBC	2pcs
C		BARREL NUT	12pcs
D		WOODEN PLUG	12pcs
E		Ø8 x 35mm WOOD DOWEL	24pcs
F		ADJUSTER	2pcs
G		M4 X 25mm SCREW (F) M4 X 25mm SCREW (Q/K)	38pcs 40pcs
H		ALLEN KEY	1pcs

