JOFRAN INC.

ASSEMBLY INSTRUCTIONS & PARTS IDENTIFICATION


MODEL # 2021-78

WILLOW CREEK EXTENSION DINING TABLE


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment


Key Parts					
No	Code	Q'Ty	Description		
1	2021-78P24	1 pc	Table Top		
2	2021-78P02	4 pcs	Table Leg		
3	2021-78P01A	4 pcs	Apron Spacer		
4	2021-78P01F	4 pcs	Floor Glide		
5	2021-78P13	2 sets	Extension Mechanism		
6	2021-78P13L	4 sets	Extension Lock		

Hardware kit 2021-78P01					
No	Description Q'Ty				
A	9	Flat washer 5/16"	8 pcs		
В	0	Lock washer 5/16"	8 pcs 8 pcs		
C	9	Nut 5/16"	8 pcs		
D	~	Key wrench	1 pc		



- Carefully lay Table Top upside down on a smooth flat surface to prevent scratches.
- Affix each Leg to each corner of the Table Top as shown in illustration. Insert a Flat Washer, Lock Washer and Nut on to the bolts of each Leg
- Once all Legs are in place, fully tighten nuts by turning clockwise using provided Key Wrench until secure. (See Detail A)





STEP 2

Fully extend both sides of the table and carefully place the removable leaf in place lining up the pins and holes with the table top. Reverse procedure for storage.