




Functional Design, Better Home





ASSEMBLY INSTRUCTION

















CT005AH/CT005AG

+1888 666 9122
customerservice@povison.com



















Parts and Operation Elements

				
Drawer Front Board	Drawer Left Board	Drawer Right Board	Drawer Back Board	Drawer Bottom Board
① 1pc	② 1pc	③ 1pc	④ 1pc	⑤ 1pc
				
Middle Vertical Board	Right Side Board	Middle Horizontal Board	Top Board	Bottom Board
⑥ 1pc	⑦ 1pc	⑧ 1pc	⑨ 1pc	⑩ 1pc
				
Left Side Board	Metal Side Frame	Metal Horizontal Bar	Shelf	
⑪ 1pc	⑫ 2pcs	⑬ 4 pcs	⑭ 1pc	


Hardware

					
Cam Bolt	Cam Lock	Dowel	4x30mm Screw	4x14mm Screw	3.5x10mm Screw
A 20pcs	B 20pcs	C 18pcs	D 10pcs	E 2pcs	L 4pcs
					
4 x 6mm bolt	Drawer Slide	Handle	4x25mm Screw	6x25mm bolt	Round Sticker For Cam Lock Hole
F 2 pcs	G 2 pcs	H 1 pc	I 16pcs	J 8pcs	K 20pcs
					
Dual Using Screw Driver					
M 1 pc					

1 1-1




1-2




A		x4
B		x4
D		x4
E		x2
H		x1

1-3





1-4




- 1: Use Screw D Connect Number 2&3&4 panel, all groove should align
- 2: Push Number 5 panel into the groove on 2&3&4 panel.
- 3: Assemble 4xA cam bolt on number 1 panel, assemble 1&2&3&4 panel, then use 4xB cam lock locked them.
- 4: Finally use 2xE screw lock the H handle to number 1 panel.

2





L		x2
G		x1




- Using 2xL screw lock the G Slide to number 7 board as picture.
1. The arrow on the G Slide points to the front side and match the first hole to the hole on the board, then use L screw to lock it.
 2. Match number 14 hole on the slide to the hole on the board, then lock it.

3






L		x2
G		x1



- Using 2xL screw lock the G Slide to number 6 board as picture.
1. The arrow on the G Slide points to the front side and match the first hole to the hole on the board, then use L screw to lock it.
 2. Match number 14 hole on the slide to the hole on the board, then lock it.


4



- A  x4
- C  x4

Assemble 4xA Cam Bolt and 4xC Dowels to number 6&7 board as picture.

5






- B  x4

Conect number 6&7&8 board, then use 4xB Cam Lock to lock them.

Pls notice the side of number 8 board which has 4 cam lock hole need forward to the side with slide as picture.


6



- A  x9
- C  x7

Assemble 9xA Cam Bolt and 7xC Dowels to number 9 board.


7




- B  x9

Conect number 6&7&8&9 &11board as picture, then use 9xB Cam Lock to lock them..




8


c  x7



Assemble 7xC dowels as picture.


9


A  x3
 B  x3
 D  x6



1. Assemble 3xA cam bolt to number 10 board as picture.
 2. Turn around the number 10 board connect to number 6&7&11 board. Then use 6xD screw and 3xB Cam Lock to lock them as picture.


10


J  x8




10. Use 8xJ bolt to connect 2x number 12 metal side frame and 4x number 13 metal horizontal bar.

11


I  x8




Use 8xI screw to lock the metal part to bottom of wood parts (number 10 board). Please notice to align the hole on the metal and wood parts.

12**I T x8**

Use 8xI screw to lock the metal part to bottom of wood parts (number 10 board).Pls notice to align the hole on the metal and wood parts.

13**F T x2**

Assemble the drawer to coffee table.Pull out the double side slide then match the groove on the drawer,then use 2xF screw to lock them.Pls notice the slide should full fill the groove.



Overall Effect