




Assembly Instruction

Storage Cabinet

MODEL : 96000



Customer Service


NEED HELP? For replacement requests or product inquiries, please contact our Customer Service by email us at

XXX or call us at XXX

Thank you for selecting XXX!

PARTS LIST

A	LEFT END (1)
B	RIGHT END (1)
C	DOOR (2)
D	BACK (1)
E	FIXED SHELF (3)
F	ADJUSTABLE SHELF (2)
G	SKIRT (1)




USEFUL HINTS BEFORE YOU START:


1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, soft and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.

HARDWARE LIST


1 WOOD DOWEL - 2




2 METAL BRACKET - 4




3 HINGE - 4




4 METAL PIN - 8




5 NAIL - 40




6 PULL - 2



7 BUMPER CARD - 1




8 APPLIQUE CARD - 1




9 1/2" FLAT HEAD SCREW - 32



11 15/16" PAN HEAD SCREW - 4




96 FURNITURE TIPPING RESTRAINT KIT - 1





10 1-9/16" FLAT HEAD SCREW - 12





Step 1




 

1-9/16" FLAT HEAD SCREW
(12 used in this step)


Step 2




Step 3




Step 4



Step 5





Step 6




9

1/2" FLAT HEAD SCREW
(8 used in this step)



Step 7

  — 9


1/2" FLAT HEAD SCREW
(8 used in this step)




Step 8




Use the two
elongated holes.



Step 9





15/16" PAN HEAD SCREW
(4 used for the PULL)




Step 10

Mark and drill a 1/8" hole into the wall stud.





Use the short screw through the hole in the strap and into the PANEL (E).





Step 11

Mark and drill a 3/8" hole into the wall.



Step 12



Step 13

