



# SW 8591 - F/Q/K

1.




Attach the footboard post (P4) to the rail (P5).  
You will need to use hardware:  
C = 2pcs  
E = 4pcs  
G = 1pc

2.




Attach the headboard lower post (P3) to the rail (P5).  
You will need to use hardware:  
C = 2pcs  
E = 4pcs  
G = 1pc

3.



After that, attach the side rail (P6) to the rail (P5) using hardware:  
D = 8pcs  
H = 1pc

4.



Attach the headboard panel (P1) to the headboard upper post (P2) using hardware:  
A = 6pcs  
E = 4pcs  
F = 6pcs  
G = 1pc  
J = 6pcs

**BACK VIEW**

## WARNING!!

- Remove hardware from box and sort by size.
- Please check to see that hardware and parts are present prior start of assembly.
- Please follow attached instruction in the same sequence numbered to ensure fast and easy assembly.
- Do not use this bed if any part is broken, torn or missing.
- The assembly of this product requires two people.
- Do not use any power tools as this may damage the frame and will invalidate any claim.

## PART LIST


P1		Headboard Panel =	1pc
P2		Headboard Upper Post =	L-1pc R-1pc
P3		Headboard Lower Post =	L-1pc R-1pc
P4		Footboard Post =	2pcs
P5		Rail =	2pcs
P6		Side Rail =	L-1pc R-1pc
P7		Center Rail =	1pc
P8		Support Leg =	2pcs
P9		Bed Slats =	14pcs

## HARDWARE LIST

A		M6 X 80MM JCBC =	6pcs
B		M6 X 50MM JCBC =	6pcs
C		M6 X 60MM JCBC =	8pcs
D		M8 X 16MM JCBB =	8pcs
E		M8 X 30MM WOOD DOWEL =	12pcs
F		M6 X 13MM BARREL NUT =	6pcs
G		ALLEN KEY M4 =	1pc
H		ALLEN KEY M5 =	1pc
I		M4 X 25MM SCREW =	14pcs
J		WOODEN BUTTON PLUG =	14pcs
K		ADJUSTER =	2pcs



5.




First, attach the headboard lower post (P3) to the headboard upper post (P2). You will need to use hardware:


- B = 4pcs
- G = 1pc
- J = 4pcs

After that, attach the headboard upper post (P2) to the side rail (P6) using hardware:

- C = 4pcs
- G = 1pc
- J = 4pcs



6.





Attach the adjuster (K) to the support leg (P8). After that, attach the support leg (P8) to the center rail (P7). You will need to use hardware :


- B = 2pcs
- G = 1pcs
- K = 2pcs

Attach the center rail (P7) between the rail (P5) using hardware:

- I = 2pcs



7.



Lastly, lay the bed slats (P9) between the side rail (P6) using hardware:

- I = 12pcs

**\*\*Apply pressure with your knee to the side rail whilst attaching the slats to ensure that the slats are flush against the inside of the side rail.**

## WARNING!!

- Remove hardware from box and sort by size.
- Please check to see that hardware and parts are present prior start of assembly.
- Please follow attached instruction in the same sequence numbered to ensure fast and easy assembly.
- Do not use this bed if any part is broken, torn or missing.
- The assembly of this product requires two people.
- Do not use any power tools as this may damage the frame and will invalidate any claim.

## PART LIST

P1		Headboard Panel =	1pc
P2		Headboard Upper Post =	L-1pc = R-1pc
P3		Headboard Lower Post =	L-1pc = R-1pc
P4		Footboard Post =	2pcs
P5		Rail =	2pcs
P6		Side Rail =	L-1pc = R-1pc
P7		Center Rail =	1pc
P8		Support Leg =	2pcs
P9		Bed Slats =	14pcs

## HARDWARE LIST


A		M6 X 80MM JCBC =	6pcs
B		M6 X 50MM JCBC =	6pcs
C		M6 X 60MM JCBC =	8pcs
D		M8 X 16MM JCBB =	8pcs
E		M8 X 30MM WOOD DOWEL =	12pcs
F		M6 X 13MM BARREL NUT =	6pcs
G		ALLEN KEY M4 =	1pc
H		ALLEN KEY M5 =	1pc
I		M4 X 25MM SCREW =	14pcs
J		WOODEN BUTTON PLUG =	14pcs
K		ADJUSTER =	2pcs



**ASSEMBLY INSTRUCTION**

**SW 8000 - 63D6D**















**REAR**











**FRONT**




# PART LIST

<p><b>1</b> Top Panel</p>  <p>1pc</p>	<p><b>2</b> Bottom Panel</p>  <p>1pc</p>	<p><b>3-L</b> Side Panel (L)</p>  <p>1pc</p>	<p><b>3-R</b> Side Panel (R)</p>  <p>1pc</p>	<p><b>4</b> Division</p>  <p>1pc</p>	<p><b>5</b> Rail</p>  <p>4pcs</p>
<p><b>6</b> Post</p>  <p>6pcs</p>	<p><b>7</b> Back Panel</p>  <p>2pcs</p>	<p><b>8</b> Dw Front Panel</p>  <p>6pcs</p>	<p><b>9-L</b> Dw Side Panel (L)</p>  <p>6pcs</p>	<p><b>9-R</b> Dw Side Panel (R)</p>  <p>6pcs</p>	<p><b>10</b> Dw Rear Panel</p>  <p>6pcs</p>
<p><b>11</b> Dw Support Rail</p>  <p>6pcs</p>	<p><b>12</b> Dw Base Panel</p>  <p>6pcs</p>				


# HARDWARE LIST

<p><b>A</b> MINIFIX SPREDING DOWEL 24MM</p>  <p>18pcs</p>	<p><b>B</b> MINIFIX HOUSING Ø15*12MM</p>  <p>18pcs</p>	<p><b>C</b> WOOD DOWEL M8*30MM</p>  <p>52pcs</p>	<p><b>D</b> SCREW M4*25MM</p>  <p>48pcs</p>	<p><b>E</b> SCREW M4*30MM</p>  <p>24pcs</p>	<p><b>F</b> M6 X 40MM JCBC</p>  <p>6pcs</p>
<p><b>G</b> ALLEN KEY M4</p>  <p>1pc</p>	<p><b>H</b> HANDLE</p>  <p>6sets</p>				

# STEP 1



# STEP 2



F X 6pcs



G X 1pc




A X 9pcs




B X 9pcs




C X 6pcs





# STEP 3




# STEP 4




  
C X 16pcs


  
E X 8pcs




  
A X 9pcs

  
B X 9pcs



  
C X 6pcs




# STEP 5




# STEP 6




E X 16pcs



C X 12pcs





D X 24pcs








# STEP 7

DRAWER X 6



# STEP 8


DRAWER X 6



C X 12pcs




D X 24pcs






# STEP 9

**DRAWER X 6**



# STEP 10


**\*CONTINUE TO ASSEMBLY  
ANTI TIPPING KITS\***



# ASSEMBLY INSTRUCTION













## SW 8000-63NS2D

**REAR**












**FRONT**


# PART LIST

<p><b>1</b> Top Panel</p>  <p>1pc</p>	<p><b>2</b> Bottom Panel</p>  <p>1pc</p>	<p><b>3</b> Side Panel (left)</p>  <p>1pc</p>	<p><b>4</b> Side Panel (right)</p>  <p>1pc</p>	<p><b>5</b> Support Rail</p>  <p>2pcs</p>	<p><b>6</b> Back Panel</p>  <p>1pc</p>
<p><b>7</b> Post</p>  <p>4pcs</p>	<p><b>8</b> Drawer Side Panel (left)</p>  <p>2pcs</p>	<p><b>9</b> Drawer Side Panel (right)</p>  <p>2pcs</p>	<p><b>10</b> Drawer Back Panel</p>  <p>2pcs</p>	<p><b>11</b> Drawer Front Panel</p>  <p>2pcs</p>	<p><b>12</b> Drawer Base Panel</p>  <p>2pcs</p>


# HARDWARE LIST

<p><b>A</b> MINI FIX SPREADING BOLT 24MM</p>  <p>12pcs</p>	<p><b>B</b> MINIFIX HOUSING Ø15*12MM</p>  <p>12pcs</p>	<p><b>C</b> WOOD DOWEL M8*30MM</p>  <p>16pcs</p>	<p><b>D</b> CSK SCREW M4*30MM</p>  <p>4pcs</p>	<p><b>E</b> JCBC M6X40MM</p>  <p>4pcs</p>	<p><b>F</b> PAN HEAD M3.5*16MM</p>  <p>12pcs</p>
<p><b>G</b> CSK SCREW M4*25MM</p>  <p>16pcs</p>	<p><b>H</b> HANDLE 135MM</p>  <p>2sets</p>	<p><b>I</b> M4 ALLEN KEY</p>  <p>1pc</p>			


# STEP 1





# STEP 2



## BOTTOM PANEL




  
C X 8pcs

  
D X 4pcs





  
A X 6pcs

  
B X 12pcs


  
C X 8pcs




# STEP 3



# STEP 4



TOP PANEL



E X 4pcs





I X 1pc





A X 6pcs



# STEP 5





  
F X 12pcs




# STEP 6

**DRAWER X 2**




  
G X 8pcs




# STEP 7

**DRAWER X 2**



# STEP 8

**DRAWER X 2**






**G X 8pcs**







# STEP 9

**DRAWER X 2**



# STEP 10



  
H X 2set



# ASSEMBLY COMPLETE

